

SERVICE



BULLETIN



PLEASE NOTE
THE SERVICE
DEPT FAX
NUMBER
01536 721110

TO: All Versalift Users

SUBJECT: Emergency Motor Operation

SERVICE BULLETIN REF. 06/0801

DATE: August 2006

To prevent premature failure of the emergency motors it is essential that they are used correctly, as specified in the machine operator manuals.

The motors are designed purely for emergency use and should only be used if the vehicle engine or hydraulic pump has failed to recover the boom and allow the operator to get back to ground level. To ensure a prolonged life for the motor it should only be operated in 30 second cycles with a resting time of 60 seconds between cycles to eliminate the possibility of overheating and burn out of the motor.

In addition to these precautions it is essential that the motor is tested as part of the machine's daily pre use inspection to keep the solenoid operating freely. If this daily testing is not carried out it is possible that the solenoid could stick or seize preventing the motor from operating in an emergency.

This bulletin is for technical information purposes only and does not constitute authority for mandatory replacement of parts or warranty claim submission.

If you have any questions, or if further information is required, please contact the Versalift Technical Help Line on 01536 721010