

SUBJECT: Levelling Rod Bearings

SERVICE BULLETIN REF. 05/0501

DATE: March 2005

As part of our continued product enhancement programme we have introduced changes to the cage levelling system on all ET models with a 110[°] fly boom.

The levelling rods and fly boom cylinder rod have been fitted with self aligning bearings fitted with grease nipples. In addition the left hand rod has been fitted with adjustable ends for easier alignment.

It is recommended that the self aligning bearings are lubricated every three months. Grease should be pumped into the bearing until it extrudes from both sides of the bearing.

This bulletin is for technical information purposes only and does not constitute authority for mandatory replacement of parts or warranty claim submission.

If you have any questions, or if further information is required, please contact the Versalift Technical Help Line on 01536 721010

Versalift Distributors (UK) Ltd 1 Altendiez Way Latimer Park Burton Latimer Northants. NN15 5YZ Tel. 01536 721010 Fax 01536 721110 Email: admin@versalift.co.uk